## PHAZR-5 REMOTE CONTROL PROGRAMMING

## **STB PROGRAMMING:**

- Press and hold the STB button, in about 5-7 secs the STB button will blink once.
- Still holding the STB button press the number 9 on the keypad the STB light will blink twice.
- Release the STB button and it will blink twice to indicate it is complete.



## PROGRAMMING REMOTE TO YOUR TV

- Press and hold the TV button, in about 5-7 secs the STB button will blink once.
- Still holding the TV button press the number on the keypad from the quick setup code that matches the TV's brand the TV light will blink twice.
- Release the TV button and it will blink twice to indicate it is complete.

TV	
<b>Quick Number</b>	Manufacturer/Brand
0	SANYO
1	SONY
2	SAMSUNG
3	LG
4	TOSHIBA
5	PANASONIC
6	PHILIPS
7	HITACHI
8	SHARP
9	VIZIO